



Reg no: 2017/362363/07  
SA Vat No: 4700280045  
Tax no: 9658182176  
Import/Export Reg No: 21798845

Operating and maintenance Instructions for Quick Pitch Drop Down Kitchen Combo



127 Mosaic street    Mauritz Prinsloo  
Silvertondale    +27 72 125 9343  
Pretoria, Gauteng    mauritz@quickpitchsa.co.za  
South Africa    www.quickpitchsa.co.za

### How to Open

- 1) In front of the Drop-Down Kitchen Combo is a Stainless-Steel slam lock running across the fridge slide. Push the slam lock down carefully and pull the fridge slide towards yourself until fully extended. (See red line – Fig. 1)
- 2) Pull the handle towards you, this will drop the fridge and drawer downwards. (See yellow line – Fig.1)
- 3) Right in front of the Drop-Down Kitchen Combo there is 2 Stainless-Steel slam locks. Pull these slam locks towards each other and pull the drawer towards you. (See white arrows – Fig. 2)
- 4) Pull the handle on the drawer towards you.
- 5) Use both hands (fingers in the precut holes in the top tabletop) and pick the top up and towards yourself. (See green line – Fig. 2)
- 6) At the front of the drawer there is a hole in the cutlery drawer to pull the cutlery drawer out. (See blue dot – Fig. 2)

### How to Close

- 1) Make sure the tabletop is back in the original closed position. (Make sure to close the tabletop using the 2 x holes to stop your fingers from getting pinched between the tabletop and drawer)
- 2) Close the cutlery drawer.
- 3) Push the drawer back underneath the fridge, keep pushing until the slam lock locks the drawer is in place.
- 4) Take the handle and pull up. Until the Drop-Down Kitchen Combo is in line with the mounting point of the Drop-Down Kitchen Combo.
- 5) Now push the Drop-Down Kitchen Combo back until the slam lock, is secure.

### Maintenance

- 1) Periodically check the brackets, nuts and bolts and ensure they are tight.