



Reg no: 2017/362363/07  
SA Vat No: 4700280045  
Tax no: 9658182176  
Import/Export Reg No: 21798845

### Operating and maintenance Instructions for Quick Pitch Mini Kitchen



127 Mosaic street    Mauritz Prinsloo  
Silvertondale    +27 72 125 9343  
Pretoria, Gauteng    mauritz@quickpitchsa.co.za  
South Africa    www.quickpitchsa.co.za

### How to Open

- 1) Right in front of the Mini Kitchen there is 2 Stainless-Steel slam locks. Pull these slam locks towards each other and pull the drawer towards you.
- 2) Pull the handle towards you Pull the drawer until fully extended, once the drawer is fully extended, the fridge will start to drop down behind the drawer. Keep pulling until the Mini Kitchen is fully extended.
- 3) Take both hands (fingers in the precut holes in the top tabletop) and pick the top up and towards yourself.
- 4) At the front of the drawer there is a hole in the cutlery drawer to pull the cutlery drawer out.
- 5) Under the drawer is another tabletop that may be pulled out to the side.

### How to Close

- 1) Make sure both tabletops are back in their original closed position. (Make sure to close the tabletop using the 2 x holes to stop your fingers from getting pinched between the tabletop and drawer)
- 2) Close the cutlery drawer.
- 3) Push the drawer back the fridge will slide up and the drawer will follow and locate underneath the fridge, keep pushing until the slam lock locks the drawer is in place.

### Maintenance

- 1) Periodically check the brackets, nuts and bolts and ensure they are tight.