

GENERATOR & REGULATOR**1997 STARTING & CHARGING SYSTEMS Mazda - Generators & Regulators****DESCRIPTION & OPERATION**

Generator is a conventional 3-phase, self-rectifying type with 6 diodes (3 positive and 3 negative) that rectify current. Internal regulator is solid-state type.

ADJUSTMENTS**BELT DEFLECTION**

Measure belt deflection in center of longest pulley-to-pulley span. See **BELT DEFLECTION SPECIFICATIONS** table. If belt deflection is not as specified, adjust as necessary.

BELT DEFLECTION SPECIFICATIONS

Application	⁽¹⁾ Deflection - In. (mm)
New Belt	0.22-0.28 (5.5-7.0)
Used Belt	0.24-0.30 (6.0-7.5)
⁽¹⁾ With 22 lbs. (10 kg) applied to belt.	

TROUBLE SHOOTING

NOTE: See **TROUBLE SHOOTING** article in **GENERAL INFORMATION**.

TROUBLE SHOOTING PRECAUTIONS

Observe the following precautions when trouble shooting or testing charging system:

- Obtain code number and deactivate audio anti-theft system before disconnecting battery (if equipped).
- DO NOT reverse battery cable connections. Rectifier will be damaged.
- DO NOT use high voltage type testers.
- Battery voltage should always exist at generator terminal "B".
- DO NOT ground generator terminal "L" while engine is running.
- DO NOT start engine with connector disconnected from generator terminals "L" and "S".
- DO NOT apply battery voltage to terminal "L".

ON-VEHICLE TESTING

*** PLEASE READ FIRST ***

1997 Mazda MX-5 Miata

GENERATOR & REGULATOR 1997 STARTING & CHARGING SYSTEMS Mazda - Generators & Regulators

NOTE: Check generator wiring harness connections and drive belt tension. Battery must be fully charged before testing. Wait at least 30 seconds after starting engine before measuring system voltage.


CAUTION: Ensure generator terminal "B" does not contact ground.

GENERATOR OUTPUT

1. Connect an ammeter (100-amp minimum) in-line between generator terminal "B" connector and terminal "B" of wiring harness connector. See **Fig. 1** . Turn headlights and all accessories on. Depress brake pedal. Operate engine at 2500-3000 RPM.
2. Measure and record generator output. See **GENERATOR MAXIMUM RATED OUTPUT** table. If amperage is as specified, go to next step. If amperage is not as specified, repair or replace generator.
3. Turn off headlights and all accessories. Release brake pedal. Operate engine at 2500-3000 RPM and measure amperage under no-load condition. No-load amperage should be 5 amps or greater. If amperage is as specified, go to next step. If amperage is not as specified, repair or replace generator.
4. Operate engine at 2500-3000 RPM. Measure voltage between ground and terminals "S" and "L". If 14.1-14.7 volts does not exist, repair or replace generator. If 14.1-14.7 volts exists, generator output is okay.

GENERATOR MAXIMUM RATED OUTPUT

Application	Amps
A/T	70
M/T	65



93D00706

Fig. 1: Identifying Generator Terminals
Courtesy of MAZDA MOTORS CORP.

BENCH TESTING

1997 Mazda MX-5 Miata

GENERATOR & REGULATOR 1997 STARTING & CHARGING SYSTEMS Mazda - Generators & Regulators

RECTIFIER/DIODE ASSEMBLY

1. Using an ohmmeter, check continuity of each diode in both directions (polarity). See **Fig. 2** thru **Fig. 4** . If diode shows high resistance in one direction and low resistance in other direction, diode is okay.
2. If diode shows low resistance in both directions, diode is shorted. If diode shows high resistance in both directions, diode is open. If any diode is defective, replace rectifier assembly.

ROTOR & SLIP RINGS

Measure resistance between rotor slip ring contacts. See **Fig. 5** thru **Fig. 9** . If resistance is not within specification, replace rotor. See **ROTOR RESISTANCE SPECIFICATIONS** table. Check continuity between individual slip rings and rotor core/shaft. If continuity exists, replace rotor.

ROTOR RESISTANCE SPECIFICATIONS


Application	(1) Ohms
Miata	3.5-4.5
(1) If continuity does not exist, replace rotor.	

STATOR

Check continuity between stator coil leads and stator core. See **Fig. 5** thru **Fig. 9** . If continuity exists, replace stator. Check continuity between leads of stator coil. If continuity does not exist, replace stator.

BRUSHES

Replace brushes if worn to limit line. See **Fig. 5** thru **Fig. 9** . Replace brush springs if corroded. For brush replacement procedure, see **OVERHAUL** .



96B06045

Fig. 2: Testing Rectifier Diodes
Courtesy of MAZDA MOTORS CORP.





Fig. 3: Rectifier Schematic
 Courtesy of MAZDA MOTORS CORP.

Negative	Positive	Continuity
E	Pn, P1, P2, P3	Yes
B		No
T		No
Pn, P1, P2, P3	E	No
	B	Yes
P1, P2, P3	T	Yes
Pn		No

Fig. 4: Rectifier Continuity Test Chart
Courtesy of MAZDA MOTORS CORP.



96C06055

Fig. 5: Testing Generator Stator, Rotor & Brushes
Courtesy of MAZDA MOTORS CORP.




Fig. 6: Checking Stator Winding Continuity
Courtesy of MAZDA MOTORS CORP.

Standard: .85" (21.5 mm)

Minimum: .31" (8.0 mm)




Fig. 7: Measuring Brush Wear
Courtesy of MAZDA MOTORS CORP.




Fig. 8: Checking Rotor For Shorts
Courtesy of MAZDA MOTORS CORP.




Fig. 9: Checking Rotor Resistance
Courtesy of MAZDA MOTORS CORP.

OVERHAUL

DISASSEMBLY

1. Place a 200-watt soldering iron against rear bearing for 3-4 minutes to heat rear cover to 122-140°F (50-60°C). Carefully separate front case and rotor from rear cover and stator. See **Fig. 10** thru **Fig. 15** and **Fig. 17**.
2. Position rotor in vise. Remove pulley. Disassemble pulley, rotor and front case. Remove front bearing from front case. Using a bearing puller, remove rear bearing.
3. Remove "B" terminal nut and bushing from rear cover. Remove screws from brush holder and rectifier. Separate rear cover and stator. When unsoldering rectifier and stator leads, disconnect as quickly as possible (5 seconds maximum) to avoid damage to rectifier. To remove brushes from holder, unsolder pigtail from terminal.

REASSEMBLY

Brush Installation

1. Install brush and spring into holder. Allow brush to extend out of holder until wear limit line extends .08-.16" (2-4 mm) beyond end of brush holder. See **Fig. 16**. Solder pigtail onto brush holder.
2. Insert spring and brush into brush holder. Using a spring scale, pull brush into holder until end of brush protrudes .08" (2.0 mm) from holder. See **Fig. 10** thru **Fig. 15**. Note reading on spring scale. Replace spring if tension is not 5.6-15.5 ozs. (160-440 g).




Fig. 10: Heating Rear Bearing Housing
Courtesy of MAZDA MOTORS CORP.





Fig. 11: Removing Rear Bearing

Courtesy of MAZDA MOTORS CORP.



96B06069

Fig. 12: Unsoldering Rectifier From Regulator

Courtesy of MAZDA MOTORS CORP.






Fig. 13: Replacing Brushes
Courtesy of MAZDA MOTORS CORP.



96E06075

Fig. 14: Measuring Brush Spring Tension
Courtesy of MAZDA MOTORS CORP.



96J06073

Fig. 15: Inserting Wire To Retain Brushes For Reassembly
Courtesy of MAZDA MOTORS CORP.





Fig. 16: Measuring Installed Depth Of Brush
Courtesy of MAZDA MOTORS CORP.

1997 Mazda MX-5 Miata

GENERATOR & REGULATOR 1997 STARTING & CHARGING SYSTEMS Mazda - Generators & Regulators



- | | |
|---------------------------|------------------|
| 1. Pulley Nut | 9. Stator |
| 2. Pulley | 10. Brush Shield |
| 3. Spacer | 11. Brush Holder |
| 4. Front Case | 12. Rectifier |
| 5. Front Bearing | 13. Rear Cover |
| 6. Bearing Retainer Plate | 14. Nut |
| 7. Spacer | 15. Bushing |
| 8. Rotor | |


93A82362

Fig. 17: Exploded View Of Generator
Courtesy of MAZDA MOTORS CORP.

WIRING DIAGRAMS

1997 Mazda MX-5 Miata

GENERATOR & REGULATOR 1997 STARTING & CHARGING SYSTEMS Mazda - Generators & Regulators



1997 Mazda MX-5 Miata

GENERATOR & REGULATOR 1997 STARTING & CHARGING SYSTEMS Mazda - Generators & Regulators

Fig. 18: Charging System Wiring Diagram