



FITMENT INSTRUCTIONS

WIND DEFLECTOR

TOOLS REQUIRED:

- 13mm Spanner
- 5 Allen key

TO FIT

Please use the images with the steps as a reference to help you with the fitment.

1. Open the wind deflector brackets carefully. Make sure you do not cut the brackets while unwrapping.
2. Using the (2) two Stainless steel brackets provided. Slide the M8 bolt into the bottom slot of the load bar, loosely fasten the brackets.
3. Use a measuring tape, and measure the mounting holes on the wind deflector. Space the stainless mounting brackets on the load bar the same length as the mounting holes. (1235mm)
4. Tighten the stainless steel brackets on the load bars using a 13mm spanner. Thereafter, fix the wind deflector to the stainless steel brackets and tighten using a 5mm Allen key and 13mm spanner.
5. Double-check the measurement and ensure the wind deflector is centered on your vehicle.



Stainless steel mounting bracket

PLEASE DON'T HESITATE TO CONTACT US IF YOU NEED ANY SUPPORT REGARDING THE FITMENT.
THANK YOU FOR YOUR SUPPORT. WE HOPE YOU LOVE YOUR QUICK PITCH PRODUCT.