



FITMENT INSTRUCTIONS

QUICK-EN-SUITE BAG FITMENT

TOOLS REQUIRED:

- 13 Spanner
- Chamfer Tool
- 4 x M6 Bolt (included)

TO FIT

Please use the images as a reference to help you fit the Awning to load bar brackets.

1. Open the Quick-en-Suite bag and unwrap the shower carefully to ensure there are no cuts while unwrapping the bag.
2. Use a chamfering tool to open the four (4) holes on the backbone of the Quick-en-Suite.



Chamfering mounting holes

3. Insert 4 x M6 bolts into the mounting holes on the backbone of the shower bag.

4. Insert these bolts into the mounting brackets or mounting surface.



5. When the bolts are inserted tighten using a 13 spanner.



6. Enjoy your en suite privacy.



PLEASE DONT HESITATE TO CONTACT US IF YOU NEED ANY SUPPORT REGARDING THE FITMENT.
THANK YOU FOR YOUR SUPPORT, WE HOPE YOU LOVE YOUR QUICK PITCH PRODUCT.