



FITMENT INSTRUCTIONS

LOW MOUNT BRACKETS

TOOLS REQUIRED:

- 13 Spanner or 13mm socket

TO FIT

Please use the images with the steps as a reference to help you with the fitment.

1. Open the low-mount brackets carefully. Ensure you do not cut the brackets while unwrapping.
2. **Insert** the M8 hex head bolt into the foot of the bracket and slide it into your mounting rail.
3. Position the brackets in their correct locations and tighten them lightly to allow space for adjustment.
4. **Slide** the load bar into place and adjust the angle as needed, using your load bars and the M8 hex head bolts on the side of the low-mount brackets
5. Measure the load bar to ensure it is centered. Once centered, fully tighten the low-mount brackets using a 13mm spanner.
6. The load bars are now mounted as low as possible.
(We recommend using 4 low-mount brackets per load bar.)



PLEASE DONT HESITATE TO CONTACT US IF YOU NEED ANY SUPPORT REGARDING THE FITMENT.
THANK YOU FOR YOUR SUPPORT, WE HOPE YOU LOVE YOUR QUICK PITCH PRODUCT.