

FITMENT INSTRUCTIONS

QUICK-EN-SUITE MAXX

TOOLS REQUIRED:

- 13 Spanner
- Chamfer Tool
- Drill
- 4 x M8 Bolt and Lock Nut

TO FIT

Please use the images with the steps as a reference to help you with the fitment.

1. Open the Quick-en-Suite Box and unwrap the shower carefully to ensure there are no cuts while unwrapping the bag.
2. Use a chamfering tool to open the four (4) holes on the backbone of the Quick-en-Suite
3. Insert 4 x M8 bolts into the mounting holes of the shower box. Thereafter, insert these bolts into the mounting surface or brackets on the vehicle.



Step 2: Chamfering tool



Step 3: Inserting of bolts in mounting holes



4. When all the bolts are inserted, tighten them on the mounting surface, using a 13mm spanner.

Enjoy your en suite privacy.



PLEASE DONT HESITATE TO CONTACT US IF YOU NEED ANY SUPPORT REGARDING THE FITMENT.
THANK YOU FOR YOUR SUPPORT, WE HOPE YOU LOVE YOUR QUICK PITCH PRODUCT.