



Reg no: 2017/362363/07
 SA Vat No: 4700280045
 Tax no: 9658182176
 Import/Export Reg No: 21798845

Quick Pitch fitment instructions - Awning to Front Runner (LHS, RHS, DC)

AWNING TO FRONT RUNNER LEFT HAND SIDE



AWNING TO FRONT RUNNER RIGHT HAND SIDE



AWNING TO FRONT RUNNER DOUBLE CAB



What's in the Box

- 1) 2 Stainless Steel Brackets (these will differ between LHS, RHS, Double Cab)
- 2) LHS & RHS
 - 11 x Hex Head m8x20mm bolts
 - 17 x m8 Lock Nuts
 - 6 x Allan cap m8x20mm bolts

127 Mosaic street Mauritz Prinsloo
 Silvertondale +27 72 125 9343
 Pretoria, Gauteng mauritz@quickpitchsa.co.za
 South Africa www.quickpitchsa.co.za

3) Double Cab

- 14 Hex Head m8x20mm bolts
- 22 x m8 Lock Nuts
- 8 x Allan cap m8x20mm

Tools Needed

- 1x 13mm spanner
- 1x m5 Allan Key

Method:

1. Remove the rear Front Runner roof rack corner piece.
 - a. (LHS Awning= Left rear corner, RHS Awning= Right Rear Corner, Double Cab LHS Awning= Both front and rear on the Left-hand side or RHS= Both front and rear on the Left-hand side.
2. Slide in the nuts in the top and bottom of the side rail on the roof rack.
3. Place the bracket over the roof racks side, align the nuts and place the bolts through the bracket and tighten them into the nuts.