

Reg no: 2017/362363/07 SA Vat No: 4700280045 Tax no: 9658182176 Import/Export Reg No: 21798845

Quick Pitch fitment instructions - QES Bag Unit





What's in the box.

- 1x QES Bag Unit

Tools needed.

- 2x 13mm Spanners
- Drill
- M8 Drill bit

Method:

- 1. The top corners of the bag unit have 2 holes on each side.
- 2. Make sure the bag at the back of the QES is straight and flush with the frame, take a m8 drill and drill through the bag's canvas.
- 3. Do not drill through the aluminium.
- 4. This is just to pierce the bag to get the bolts through.
- 5. Take 4 m8 bolts and washers put them through these holes.
- 6. Line these bolts up with the holes in the bracket and push them through take 4 m8 lock nuts and tighten the bolts and nuts.
- 7. When the Quick En Suite is opened, adjust the curtain by loosening or tightening the webbing that goes through the arms.
- 8. Ideally the curtain must be 100mm from the ground.
- 9. Then take a warm blade and melt the excess webbing shorter.