



Reg no: 2017/362363/07
SA Vat No: 4700280045
Tax no: 9658182176
Import/Export Reg No: 21798845

Quick Pitch fitment instructions - QP Quick En Suite to QP RTT



What's in the box.

- 2x m8 Cup Square bolts and nuts
- 2x QES to RTT brackets
- 4x m8 Allan Cap bolts and nuts

Tools Needed

- 1x 13mm Spanner
- 1x 5mm Allan Key

Method:

1. Slide the 2 Cup Square bolts in on the side rail of the bottom side extrusion of the RTT.
2. Place the bracket over the bolt.
3. Tighten the nuts securing the brackets in place making sure the QES holes will line up with the bracket holes.