

Reg no: 2017/362363/07 SA Vat No: 4700280045 Tax no: 9658182176 Import/Export Reg No: 21798845

Quick Pitch fitment instructions - Quick Pitch Drawers





What's in the box?

- 1x Drawer
- 4x Stacking plates.
- 4x M4x12mm Counter Sunk bolts
- 4x M4 Lock Nuts

NO BOLTS ARE SENT WITH- DUE TO DIFFERENT FITMENT OPTIONS

Tools needed.

- 1x 3mm Allan Key
- 1x 6mm Spanner
- 1x Drill
- 1x 8mm Drill Bit

Method:

- 1. On the side at the Stainless-steel slide there is 2 Susterin sliding blocks on each side of the drawer held into place with an Aluminium locking plate.
- 2. Remove the locking plates and slide the Susterin block out. Take out the drawer.
- 3. Place the Quick Pitch Drawer outer shell in place.
- 4. The frame has holes on each side running from back to front.
- 5. Measure 4 holes that will work best for your application, mark them, take out the Quick Pitch Drawer then drill the holes through the base where Drawer will be mounted with an 8mm drill.
- 6. Place the Drawer back in place and pull the slide out, tighten all 4 bolts to the base.
- 7. After the frame is installed place the drawer back in the frame and line up the stainless-steel slide with sliding blocks.
- 8. Place the locking plate in position and tighten the bolts.