

FITMENT INSTRUCTIONS

QUICK-EN-SUITE WEATHER COVER

TOOLS REQUIRED:

- 5mm Drill bit
- 8mm Drill bit
- Drill
- Measuring tape

TO FIT

Please use the images with the steps as a reference to help you with the fitment.

1. Open the Quick en Suite weather cover. Be careful to cut the cover whilst opening.
2. Use a measuring tape and locate the middle of the Quick-en-Suite arm on the right-hand side when looking at the shower from the front.
3. Drill a pilot hole with a 5mm drill bit into the middle of the arm where you marked.
4. Now use your 8mm drill bit and drill through the pilot hole.
5. Insert your spring rod and set up your weather cover. (See photos below)



Setting up the Weather Cover:

1. Make sure the spring rod is through both holes, and steady enough to hang the weather cover.
2. Hang the weather cover at the top of the spring rod.
3. Take the front two elastics of the weather cover around the Q-e-S structure.
4. Take the back two elastics and make sure they are around the nut at the back (see image) for the perfect tension weather cover.



PLEASE DONT HESITATE TO CONTACT US IF YOU NEED ANY SUPPORT REGARDING THE FITMENT.
THANK YOU FOR YOUR SUPPORT, WE HOPE YOU LOVE YOUR QUICK PITCH PRODUCT.