



Reg no: 2017/362363/07  
 SA Vat No: 4700280045  
 Tax no: 9658182176  
 Import/Export Reg No: 21798845

#### Quick Pitch fitment instructions - Quick Pitch RTT



#### What's in the box.

- 1xRTT
- 4x brackets
- 4x m8 Cup Square Bolts
- 16x m8 Hex head bolts
- 20x m8 Lock nuts

#### Tools needed.

- 13mm Socket, Socket extension, Ratchet

#### Method:

**NB: PLEASE MAKE SURE ALL THE BOLTS FOR ADITIONS TO THE RTT IS IN PLACE BEFORE FITTING THE RTT**

1. Open the RTT, in the rear corners you will find brackets behind the mattress, 2 on the left and 2 on the right.
2. Remove these brackets.

3. Once the brackets are open, slide 4 cup square bolts inside rail of extrusion 2 on left and 2 on right side of base extrusion.
4. Slide 4 Hex head bolts on each side of bottom rail underneath the RTT.
5. Slide bracket over these 3 bolts and add the nuts without tightening.
6. By measuring the space between the load bars space, the brackets to the same measurement.
7. Slide 4 bolts in top rail of Quick Pitch Load bar. 2 on each side of the load bar.
8. Place RTT on top of the load bar making sure the 2 bolts on each side of the load bar are slotted in on the bottom part of the bracket.
9. Measure from the rear of the RTT to the load bar on both sides making sure the QP RTT is square, if not adjust the RTT till square.
10. Once the RTT is square, tighten the bolts that goes into the load bar first making sure the bracket sits flush with the load bar.
11. Then tighten the once on the bottom rail and lastly the once on the side rail of the RTT.