

Reg no: 2017/362363/07 SA Vat No: 4700280045 Tax no: 9658182176 Import/Export Reg No: 21798845

Quick Pitch fitment instructions - Lady Shoot



What's in the box.

- 1x Ladies Shoot (Canvas)
- 2x Brackets
- 2x Spring Rods
- 4x M8 x 20mm Cup Square + 4 lock nuts
- 2x Ladies Shoot hooks.
- 2x large flange pop rivet
- 2x pop rivet washers.

Tools Needed

- 1x 13 Spanner
- 1x Pop Rivet Gun
- 1x Soldering Iron

Method:

- 1. Mount the brackets to the side rail of the RTT.
- 2. First bracket needs to be mounted as close as possible to the back end of the RTT, with the 2 stainless steel protrusion facing towards the RTT.
- 3. The next bracket must be mounted 1360mm (Outside to outside measurement) to the front.
- 4. At the canvas at the back measure 1005mm from the base this is where the first ladies shoor hook needs to be mounted.
- 5. You mount these hooks by taking a warm soldering iron and burning a little hole for the pop rivet to go through.
- 6. From the First hook measure 800mm parallel with the base towards the front and fit the second ladies shoot hook there. This should be 930mm upwards from the base.