



FITMENT INSTRUCTIONS

GUTTER MOUNT BRACKET

TOOLS REQUIRED:

- 13 mm Spanner

Sizes are available in Small, Medium and Large.

TO FIT

Please use the images and the steps as a reference to help you with the fitment.

1. Open the Gutter Mount from the packaging, ensure that the gutter mounts include:

- 1x bolt in each bracket
- Pinch weld on the brackets foot



Pinch Weld



M8 Bolt

2. Take one gutter bracket, place the inner clamp of the bracket onto the gutter of the vehicle. Loosely tighten the gutter bracket.



Inner clamp



Outer clamp

3. Mounting the load bar: When the gutter brackets are loosely tighten on each side use the load bar. Slide the M8 hex heads on the gutter mount into the bottom rail of the load bar so that the load bar sits loosely on top of the brackets.



Load bar on gutter

4. Measuring: slowly start to tighten the gutter mount, measure the distance from the edge of the load bar to the gutter mount bracket to ensure the load bar is centered.

Measurements will differ for each car. Make sure the measurements are the same on both sides of your vehicle. .



5. If everything is lined up, slowly start to fasten all the bolts and continue to check the measurements for any changes. Make sure measurements are the same.

PLEASE DON'T HESITATE TO CONTACT US IF YOU NEED ANY SUPPORT REGARDING THE FITMENT.
THANK YOU FOR YOUR SUPPORT, WE HOPE YOU LOVE YOUR QUICK PITCH PRODUCT.