



Reg no: 2017/362363/07
SA Vat No: 4700280045
Tax no: 9658182176
Import/Export Reg No: 21798845

Quick Pitch fitment instructions - RTT Mini Max



What's in the box.

- 1x RTT Mini Maxx
- 4x Low Mount Brackets (Stowed in the RTT)
- 12x m8x 20mm
- 12x m8 Lock Nuts

Tools Needed

- 2x 13 Spanners

Method:

1. Slide in the bolts on the side of the load bar that is mounted to the RTT.
2. 2 for each bracket and 4 per side.
3. Slide the brackets over the bolt and put the lock nuts in place, do not tighten these bolts yet.
4. Align the low mount brackets with the bracket/ load bar that you will be mounting the RTT to.
5. After the low mount bracket and bracket/ load bar is aligned and fitted, tighten all the nuts making sure the tent is properly fastened.

127 Mosaic street Mauritz Prinsloo
Silvertondale +27 72 125 9343
Pretoria, Gauteng mauritz@quickpitchsa.co.za
South Africa www.quickpitchsa.co.za