



Reg no: 2017/362363/07
 SA Vat No: 4700280045
 Tax no: 9658182176
 Import/Export Reg No: 21798845

Quick Pitch fitment instructions - Awning to RTT bracket



What is in the box?

- 2 x Stainless Steel brackets
- 3 x Cup Square bolts and nuts
- 10 x m8 Allan Cap bolts and nuts

Tools Needed

- 1x 13mm spanner
- 1x m5 Allan Key
- 8mm Drill Bit
- Drill
- Sika Flex

Method

1. Slide one cup square in the side bottom extrusion rail.
2. Place the brackets hole over the bolt and push in place.
3. Slightly tighten the bolt and nut whilst holding the bracket in place.
4. Make sure the bracket is in place. Now drill the 4 x holes at the back of the RTT through the holes of the bracket.
5. Once done remove the bracket - make sure the all the shavings are removed.
6. Add sika flex around each of the holes on the RTT to seal the holes to keep the RTT water and dust tight.
7. Put the bracket in place and tighten the 4 Allan cap bolts.
8. Remove all the excess sika flex around the bracket and tighten the bolt on the side.
9. From the front of the RTT - slide in 2 cup square bolts and place the bracket over these bolts and tighten them.