




Reg no: 2017/362363/07
SA Vat No: 4700280045
Tax no: 9658182176
Import/Export Reg No: 21798845

Operating and maintenance Instructions for

Quick Pitch Drop Down Fridge Slide (Medium, Large, Extra Large)



127 Mosaic street Mauritz Prinsloo
Silvertondale +27 72 125 9343
Pretoria, Gauteng mauritz@quickpitchsa.co.za
South Africa www.quickpitchsa.co.za

How to Open

- 1) Right in front of the DDFS there is a Stainless-Steel slam lock running across the fridge slide. (See yellow line – Fig. 1)
- 2) Push the slam lock down carefully and pull the fridge slide towards yourself until fully extended. (See white arrow – Fig. 2)
- 3) Pull the handle towards you, this will bring the fridge forward and then downwards. (See red line – Fig. 3)

How to Close

- 1) Take the handle and pull up. Until the fridge is in line with the top of the drawer or the mounting point of the Drop-Down Fridge Slide.
- 2) Push the fridge back until the slam lock locks the slide in place.

Maintenance

- 1) Periodically check the brackets, nuts and bolts and ensure they are tight.