



Reg no: 2017/362363/07  
SA Vat No: 4700280045  
Tax no: 9658182176  
Import/Export Reg No: 21798845

Operating and maintenance Instructions for Quick Pitch RTT



127 Mosaic street    Mauritz Prinsloo  
Silvertondale    +27 72 125 9343  
Pretoria, Gauteng    mauritz@quickpitchsa.co.za  
South Africa    www.quickpitchsa.co.za

### How to Open

- 1) Open the 2 latches at the back of the RTT. (See white circles – Fig. 1)
- 2) Push the handle at the up to open the RTT. The gas strut will take over at a certain point, allow the gas struts to open the RTT. (See green arrow – Fig. 1)
- 3) Take the bungy cord and hook it on the base where the canvas is pop rivetted.
- 4) There are 2 stainless steel brackets at the back of the RTT on the base, these brackets are for 2 spring rods to keep the fly sheet tight. Take the 2 spring rods and place the end in the bracket. The other end bent in a Z needs to be placed through the eye lids on the corner of the flysheet to tension the fly sheet. (See blue circles – Fig. 3)
- 5) The ladder needs to be lifted horizontally to hook on the ladder bracket, once the ladder is in place,  
NB: Make sure the ladder is one solid unit before climbing up the ladder. All the steps need to click into place before climbing the ladder. If this is not done the ladder is not a solid unit and all the stress of the person climbing up on the ladder will be one point causing the ladder to break. This can result in damage to the vehicle or injury. (See red arrow – Fig. 3)
- 6) The RTT comes standard with a light, 2x USB sockets and a 12v socket. These can be located in the middle of the RTT at the back of the RTT. These are powered by an Anderson Plug on the outside of the RTT. The Anderson plug is found on the left-hand bottom of the RTT.

### How to Close

- 1) When storing bedding inside the RTT, make sure the bedding is laid out evenly and pillows are stored next to each other and not on top of each other. There should be no heaps of bedding inside the RTT.
- 2) Open one or more door completely. (This allows air to escape easily)
- 3) Remove the Ladder.
- 4) Remove the 2 spring rods from the eye lids and brackets. Store inside the RTT
- 5) Take the bungee cord and place this over the bottom end of the fly sheet and over the Quick Pitch Webbing. This will help to pull the canvas in when closing.
- 6) Pull the Quick Pitch Webbing down, once the top is  $\pm 200$ mm from the base check the sides of the tent and make sure the canvas will not get caught between the top and the base. Push the canvas in on the sides to ensure that the canvas will not be pinched.
  - a. **Do not pinch the canvas or zipper pulls between the top and the base as this will result in potential damage on the canvas.**
- 7) Once you have checked the sides of the RTT and the canvas is clear and will not get pinched between the base and the top, push the tent closed and close the latches.

### Maintenance

- 1) Periodically check the brackets, nuts and bolts and ensure they are tight.
- 2) Make sure that if bedding is stowed inside the RTT that there are no humps.
- 3) Make sure the ladder is used correctly.
- 4) Contact your closest dealer if there are any support required.