

1994 Mazda MX-5 Miata

TRANSMISSION SERVICING - M/T 1994 Manual Transmission Servicing

TRANSMISSION SERVICING - M/T

1994 Manual Transmission Servicing

IDENTIFICATION

MANUAL TRANSMISSION APPLICATION

Model	Transmission
Miata	M15M-D

LUBRICATION

SERVICE INTERVALS

Fluid Inspection & Replacement

Check fluid level(s) at least once a year. Change transmission fluids every 60,000 miles for normal driving conditions and every 30,000 miles for severe driving conditions.

CHECKING FLUID LEVEL

Transmission Fluid

Remove fill plug from transmission. Fluid should be up to bottom of fill hole on side of case.

RECOMMENDED FLUID

TRANSMISSION FLUID SPECIFICATIONS/CAPACITY

Application	Recommended Fluid
All-Season Usage	(1) SAE 75W-90
Temp. Greater Than 50°F (10°C)	(1) SAE 80W-90
	Capacity
Pints (liters)	4.2 (2.0)
(1) API GL-4 or GL-5.	

ADJUSTMENTS

GEARSHIFT LINKAGE

No external linkage adjustment is required.

TORQUE SPECIFICATIONS

1994 Mazda MX-5 Miata

TRANSMISSION SERVICING - M/T 1994 Manual Transmission Servicing

TORQUE SPECIFICATIONS

Application	Ft. Lbs. (N.m)
Drain Plug	29-43 (39-58)
Fill Plug	18-29 (24-39)